

Calculation components of NF Hourly MW values for Joint Dispatch Transmission Service

Transfer	POR	POD	OASIS Path	Transmission Provider	Interface Point	Notes
PRPA	PSCo	RAWHIDE	AU	W/PRPA/RAWHIDE-AULT//	PRPA	
PRPA	PSCo	AU	STVRN	W/PRPA/AULT-STVRN/TOT7 N-S/	PRPA	STVRN
PRPA	PSCo	AU	PSCO	W/PSCO//AU-PSCO	PSCo	AU
PRPA	PSCo	AU	CRG	W/PRPA/AULT-CRAIG/TOT5 E-W/	PRPA	CRG
PRPA	PSCo	CRG	PSCO	W/PSCO//CRG-PSCO/	PSCo	CRG
PRPA	PSCo					Total NF ATC is smaller of E4, E5, or E6, plus smaller of E7 or E8
PSCo	PRPA	PSCO	AU	W/PSCO//PSCO-AU	PSCo	AU
PSCo	PRPA	PSCO	STVRN	W/PSCO//PSCO-STVRN/	PSCo	STVRN
PSCo	PRPA	CRG	AU	W/PRPA/CRAIG-AULT/TOT5 W-E/	PRPA	CRG
PSCo	PRPA	PSCO	CRG	W/PSCO//PSCO-CRG/	PSCo	CRG
PSCo	PRPA					Total NF ATC is E11 + E12, plus smaller of E13 or E14
BHCE	PSCo	BHCE	READER	W/BHCT/BHCE-BHCE/BHCE-READER/	BHCT	READER
BHCE	PSCo	READER	PSCO	W/PSCO//READER-PSCO/	PSCo	READER
BHCE	PSCo	BHCE	BOON	W/BHCT/BHCE-PSCO/BHCE-BOON/	BHCT	BOON
BHCE	PSCo	BOON	PSCO	W/PSCO//BOON-PSCO/	PSCo	BOON
BHCE	PSCo	BHCE	MIDW	W/BHCT/BHCE-CRCM/BHCE-CRCMWSTATION-MIDW/	BHCT	MIDW
BHCE	PSCo	BHCE	MIDW	W/BHCT/BHCE-PSSCO/BHCE-PSCOWSTATION-MIDW/	BHCT	MIDW
BHCE	PSCo	MIDW	PSCO	W/PSCO//MIDW-PSCO/	PSCo	MIDW
BHCE	PSCo					Smaller of E17 or E18, plus smaller of E19 or E20, plus smaller of E21, E22 or E23
PSCo	BHCE	READER	BHCE	W/BHCT/BHCE-BHCE/READER-BHCE/	BHCT	READER
PSCo	BHCE	PSCO	READER	W/PSCO//PSCO-READER/	PSCo	READER
PSCo	BHCE	BOON	BHCE	W/BHCT/PSCO-BHCE/BOON-BHCE/	BHCT	BOON
PSCo	BHCE	PSCO	BOON	W/PSCO//PSCO-BOON/	PSCo	BOON
PSCo	BHCE	MIDW	BHCE	W/BHCT/CRCM-BHCE/MIDW-CRCWSTATION-BHCE/	BHCT	MIDW
PSCo	BHCE	MIDW	BHCE	W/BHCT/PSCO-BHCE/MIDW-PSCOWSTATION-BHCE/	BHCT	MIDW
PSCo	BHCE	PSCO	MIDW	W/PSCO//PSCO-MIDW/	PSCo	MIDW
PSCo	BHCE					Smaller of E26 or E27, plus smaller of E28 or E29, plus smaller of E30, E31 or E32